







EN: Instructions for use;

The EU declaration of conformity and the most recent version of the user manual can be downloaded from: www.carellurvink.nl, search for "article number" (see packaging).

CaluPrevent safety glasses are manufactured with great care, marked and comply with the requirements of Regulation (EU) 2016/425 on personal protective equipment and standard EN166:2001 on general requirements for safety glasses. The safety eyewear is meant for protecting your eyes against the impact of particles

Application and limitations:

- professional use (e.g. construction, industry and other) for eye protection in various situations
- (if appropriate for your application). non-professional use (e.g. DIY and gardening).
- 3. The glasses with clear lens can be used indoors and outdoors, the glasses with tinted lenses are for outdoor use only.
- some glasses with tinted lenses (eg with lens marking 5-3.1) can be used as protection against radiation from sunlight.
- The lenses with K and/or N coating (see marking on the lens) are intended for situations 5. where additional protection against scratches and/or fogging is required.

These safety evewear must not be used:

- during sports activities or in the vicinity of them.
- while participating in traffic or situations with limited light intensity.
- during high-risk activities such as: welding, work with electrical voltage, grinding with risk of 8. high-velocity particle impact, cooking and similar high-risk situations with risk of liquid splashes, in situations with very bright light or laser light.
- during rain, snow or mist conditions.
- if fogged up or visibility is reduced by dust.
- as vision correction, for example in case of nearsightedness 11.

CLL B.V. is not liable in case of improper use of the products. Based on the markings on the safety eyewear and the explanations in this document, assess whether the protection level of the safety glasses is sufficient for your application. Consult a safety expert (working conditions) if you are unsure whether the glasses are suitable for use in your specific situation

- before each use, inspect the safety eyewear for damage to the lenses (including scratches) and correct fit; do not use the glasses if they are damaged or do not fit properly, but replace them with a new one
- ensure that the safety eyewear are suitable for your application and that they are worn for the entire exposure time.
- protective goggles against flying particles worn over your own glasses can generate impact energy which could endanger the wearer

C. Composition / allergies:

Some safety eyewear may contain substances that can cause allergies in people who are particularly sensitive to them, resulting in irritation and/or contact allergic reactions. If allergy is suspected: discontinue use and consult a doctor or dermatologist.

D. Transport, storage, shelf life and service life:

- transport and store the safety eyewear in the original packaging at a temperature between 5°C and 40°C at a humidity <90% in a dry place, avoid exposure to moisture, direct sunlight, shocking movements, falling or pressure from heavy objects
- the safety eyewear has a shelf life of 3 years after production date (see packaging and/or marking in the frame).
- the safety eyewear has a service life of at most 1 year after the original packaging has been opened, provided that; the glasses remain undamaged, have been maintained according to instructions and are properly stored when not in use.
- stop using the safety eyewear in case of any damage or when the shelf life has expired.

E. Cleaning, disinfection and maintenance:

- the safety eyewear can be cleaned with running water or a specific cleaning product for glasses. Do not use solvents or products with abrasive properties. Dry with a scratch-free
- 2. disinfection can be done with disinfectants approved for this application in accordance with the instructions for use.
- CLL cannot accept any liability for damage to the eyewear as a result of cleaning and 3. disinfection operations and/or the effect of cleaning and disinfection agents.

F. Guarantee and warranty limitation

CLL B.V. guarantees the conformity of this product with the technical standard data of CLL B.V. on the date of delivery to the customers. Except insofar as prohibited by law, the present warranty is delivered to replace any other warranty, including any warranties for suitability for a particular use; the responsibility of CLL B.V. is limited to reimbursing the costs price of the product in question. The buyers and users of the product accept these warranty conditions, which cannot be changed by any other agreement, both orally and in writing.

G. More information:

Carel Lurvink: quality products for safety and hygiene at work. For more information, visit www.carellurvink.nl or visit our service center in Enschede (NL). Do you have questions? Send an email to our specialists via info@carellurvink.nl or call 0031

Everyone deserves a clean and safe work environment